

## 菜单结构、参数设置说明

8888	备用		01
8882	已知任意重量调试方式下已知重量的设定	(0000-9500)→表示在已知任意重量调试模式下输入已知砝码重量的数值;	0000
8883	设备所需额定载荷重量设定	(0000-9500)→表示0-9500公斤, 输入不为0的额定载荷数值后, 本系统可进行公斤显示;	0000
8884	备用		01
8885	备用		00
8886	备用		50
8887	备用		10
8888	超载动作方式设定	00→超载后继电器信号断开; 01→超载后继电器信号导通;	00
8889	版本号		


## 主控制器代码及功能

显示代码	代码说明	运行状态
8888	等待密码输入	输入密码状态
8889	等待调试	调试状态
888A	参数选项	调试状态
888B	显示为Pn(n=1-19)参数内的数值	调试状态
888C	显示为1080公斤重量	运行状态
888D	显示为额定载荷的101%	运行状态
888E	超载指示	运行状态
888F	等待空载自学习	调试状态
888G	空载自学习完成	调试状态
888H	等待额载自学习	调试状态
888I	额载自学习完成	调试状态
888J	错误代码指示	调试状态

## 常见故障代码及故障解决

故障代码	故障原因	解决对策
8880	自学习调试期间测量的额载数据≤空载数据;	请检查传感器安装是否恰当, 上电复位后起吊更重的砝码进行自学习调试;
8881	完成自学习调试前缺少对额载数据的测量;	按下[B]键后重新对额载的数据进行测量;
8882	磁铁正反面放置错误;	调整磁铁方向, 使之有符合面正对朝向控制器接收端;
8883	磁铁与控制器之间的距离过近, 超载系统极限范围;	调整磁铁与控制器之间的距离, 使之在2-10mm范围内变化;
8884	磁铁与控制器之间的距离过远, 超载系统极限范围;	调整磁铁与控制器之间的距离, 使之在2-10mm范围内变化;

## 额定载重自学习调试流程图




## 额定载重自学习调试范例详解

本系统拥有两种额定载重自学习调试方式：  
①全额载重自学习：现场有足够的砝码或重物，对精度要求很高的场合适用。  
②已知任意重量载重自学习：现场没有足够的砝码或重物，对精度要求高的场合适用。

用户根据使用现场环境不同选择以下一种调试方式进行操作：

### ● 一键快速清零调试步骤范例

(本案例为将显示屏显示的8%零点快速调整到0%的调试步骤)




备注：一键快速清零调试时，请确认当前设备处于空载状态。

### 额定载重自学习调试范例详解

#### ● 一键快速数据校正调试步骤范例



(本案例为将显示屏显示的380KG快速调整到400KG实际载重的步骤)



备注：一键快速数据校正调试时, 请确认当前实际载重数值。

#### ● 全额载重自学习调试步骤范例




(本案例为利用2000KG砝码对额定载重为2000KG的设备进行自学习操作的步骤)



备注：全额载重自学习时, P05参数应设置为00, 设备需要起吊额定载重的砝码或重物进行额载测量。当完成对P13参数数值的设置后, 正常称重时按OK可在重量和百分比之间切换显示。

#### ● 全额载重自学习调试步骤范例



(本案例为利用2000KG砝码对额定载重为2000KG的设备进行自学习操作的步骤)



备注：全额载重自学习时, P05参数应设置为00, 设备需要起吊额定载重的砝码或重物进行额载测量。当完成对P13参数数值的设置后, 正常称重时按OK可在重量和百分比之间切换显示。

#### ● 修改参数数值步骤范例

(本案例为单独修改P13参数数值的调试步骤)



备注：修改其他参数数值方式与此相同, 修改完成后按下OK键退出调试状态后数据才被记录。

#### ● 恢复出厂设置步骤范例

(本案例为恢复出厂设置的调试步骤)




警告！

当恢复出厂设置后, 出厂后所有调试的数据将被清除, 无法恢复, 请谨慎使用。


# OMS-720 USER MANUAL (VER 1.9)

NINGBO ANT ELECTRONIC CO.,LTD

## Appearance And Installation Dimensions Of The Main Controller




## Interfaces Of The Main Controller



- **NOTES**
- ① Acts when measured weight>rated load×(1+P01%);
- ② Acts when rated load×P08%≤measured weight<rated load×(1+P01%);
- ③ Acts when 0%≤measured weight<rated load×P07%;
- ④ Analog voltage output changes linearly from -10V to +10V or 0V to +10V according to P06 setting when load varies.
- ⑤ Please make sure the working voltage is AC/DC16V-45V before normal operation;

## Installation Drawing (Only for reference)



- **NOTES**
- The induction magnet has a marked side which is opposite to the main controller. The magnet is a special rare earth magnet, which is strong and must be carefully installed in the process of installation. Any time to avoid the high temperature of 100 °C in order to reduce the accuracy of the measuring demagnetization.

## The Menu Structure And Parameter Setting

Parameter	Meanings	Parameter Range	Default value
8888	Overload range setting:	00~20—Indicates 0~20%, overload relay acts when measuring load exceeds (1+p01%) rated load;	10
8888	Bouncing sensitivity setting:	00~10 — The sensitivity decreases with the value of P02 increasing;	05
8888	Spare		00
8888	Delay time setting for overload relay release;	00~05 — Indicates 0~5 seconds;	02
8888	Mode setting for rated load learning;	00 — Learning with full weight load; 04 — Learning with any known weight load;	00
8888	Analog voltage output range setting:	00~10V — Analog voltage output -10V to +10V; 01~10V — Analog voltage output 0V to +10V;	00
8888	Light load range setting:	05~75 — Indicate 5~75%, light load relay acts when measuring load is in range of 0% to P07% rated load;	05
8888	Heavy load range setting:	90~99 — Indicate 90~99%, heavy load relay acts when load is in range of P08% to (1+p01%) rated load;	90
8888	Light load contact setting:	00 — Contact closes when in light load range; 01 — Contact releases when in light load range;	00
8888	Heavy load contact setting:	00 — Contact closes, releases on overload; 01 — Contact releases, closes on overload; 10 — Contact closes, no change on overload; 11 — Contact releases, no change on overload;	10


## Procedures For Device Initialization

This system provides 2 initialization methods:

- Initialization with full weight load: if there is enough weight on site and high measurement precision required.
- Initialization with any known weight load: if there is not enough weight on site and high measurement precision required.

According to on site situation, one of the following procedures can be used for initialization, and following examples may be referred to accordingly.

- **Hotkey for prompt tare clearing**  
(In this case, change 8% to 0% in empty load)




NOTE: before clearing tare, please make sure that the equipment has no load, good for both percentage and weight displays.

## Procedures For Device Initialization

### • Fast data modification


(This case is for changing display of 380KG to real display of 400KG)



NOTE: before fast data modification, please make sure the real load weight, good for both percentage and weight.

### • Initialization with full weight rated load


(In this case, rated load is 2000KG and weight is 2000KG)



NOTE: initialization with full weight , P05 should be 00. The equipment should lift rated load. Input rated load value to P13, press OK to switch display in percentage or in weight.

### • Initialization with known weight load


(In this case, weight is 800KG and rated load is 2000KG)



NOTE: initialization with any known weight, parameter P05 should be 04 and P12 and P13 should also be modified. The equipment should lift known weight during rated load learning period. input rated load value to P13. Press OK to switch display in percentage or in weight.


### • Fast parameter modification

(Following is parameter P13 modification procedures)



NOTE: Procedure is the same for all parameters. data will be saved after press OK.

### • Reset to factory setting



WARNING After reset, all previous calibration is gone. please make sure before resetting.